






Dell Speakerphone

SP3022


Quick Start Guide





Front




Back





 www.dell.com/support/dpem



USB-A



USB-C



Regulatory Model: SP3022

www.dell.com/support
www.dell.com/support/drivers
www.dell.com/contactdell
www.dell.com/regulatory_compliance